# I THERMOWASHER

# WASHER TO FASTEN INSULATION TO WOOD

#### STRONG AND EFFICIENT

The THERMOWASHER is intended for use with structural self-tapping screws. To be used with HBS screws,  $\emptyset$ 6 ( $\emptyset$ 0.24") and  $\emptyset$ 8 ( $\emptyset$ 0.32"), length depending on thickness of the insulation to be fastened. Ideal for any type of insulation.

#### THERMAL BREAK

Incorporated hole cover to avoid thermal bridges. Large extrusions on the washer head provide for enhanced plaster adhesion.



### CODES AND DIMENSIONS

CODE	d <sub>SCREW</sub>		ахbхс		pcs
	[mm]	[in]	[mm]	[in]	
THERMO65	6   8	0.24   0.32	65 x 4 x 20	2 9/16 x 0.16 x 0.79	700



## **MATERIAL**

Propylene (PP).

#### FIELDS OF USE

The  $\emptyset$ 65 ( $\emptyset$ 2 9/16") propylene washer is compatible with  $\emptyset$ 6 and  $\emptyset$ 8 ( $\emptyset$ 0.24" and  $\emptyset$ 0.32") HBS screws; it is suitable for any type of insulation and any insulation thickness.